

SFR-Fit MTF Measurement Software FS3170

Installation / License Manual

Please read this instruction manual carefully to ensure safe use of the product.

CONTENTS

1. Pro	duct configuration1
1.1	Software1
1.2	License Key
	,
2. Ins	tall 2
2.1	Installing Software and MATLAB Runtime 2
2.1.1	About Installation
2.1.2	2 Installation Procedure
2.2	Installing CodeMeter Runtime
2.2.1	About Installation
2.2.2	2 Installation Procedure
3. Lice	ense Activation
3.1	About License
3.2	Activation Method for Online PC
3.2.1	Activation Processing
3.2.2	2 New License
3.2.3	3 Updated License
3.2.4	License Cancellation
3.2.5	5 License Transfer to Another PC20
3.3	Activation Method for Offline PC21
3.3.1	Activation Processing
3.3.2	2 New License
3.3.3	3 Updated License
3.3.4	License Cancellation
3.3.5	5 License Transfer to Another PC61
4. Lice	ense Confirmation
4.1	Checking Activation Status
5. Me	ssage at Software Startup64
5.1	Start Error64
5.2	No license found!
5.3	Licensing almost expired!
5.4	Your license has expired!
5.5	Support Page

1. Product configuration

1.1 Software

- 1. SFR-Fit installer (including MATLAB Runtime) SFR_Fit_v**_Installer_web.exe
- 2. CodeMeter Runtime Installer CodeMeterRuntime.exe

1.2 License Key

Ticket ID (sent by email)

2. Install

- 2.1 Installing Software and MATLAB Runtime
- 2.1.1 About Installation

"SFR_Fit_v**_Installer_web.exe" is the installer. This software, "SFR-Fit" and "MATLAB Runtime" will be installed.

- * MathWorks' "MATLAB Runtime" is a collection of shared libraries and code that makes software executable.
- 2.1.2 Installation Procedure
 - (1) If MATLAB Runtime is not yet installed
 - 1. Double-click "SFR_Fit_v**_Installer_web.exe" to start installation.
 - 2. Click "Next."

C SFR_Fit_v21 Installer		-	×
SFR_Fit_v21 2.101 Leader Electronics Corpration sales@leader.co.jp	C <u>o</u> nnection Settings		
< <u>B</u> ack <u>N</u> ext >	Cancel		

3. Click "Next."

L Installation Options			2		×
Choose installation folder:					
C:\Program Files\Leader\SFR_Fit\v21		B <u>r</u> owse			
	Restore	e <u>D</u> efault Folder			
Add a shortcut to the desktop				1	

To create shortcuts, check the following.



4. Click "Next."



5. "Do you accept the terms of the license agreement?" check the box and click "Next."

L License Agreement	-		×			
The MathWorks, Inc.			^			
MATLAB RUNTIME LICENSE						
IMPORTANT NOTICE BY CLICKING THE "YES" BUTTON BELOW, YOU ACCEPT THE TERMS OF THIS LICENSE. IF YOU ARE N SO, SELECT THE "NO" BUTTON AND THE INSTALLATION WILL BE ABORTED.	IOT WILLING	TO DO				
 LICENSE GRANT. Subject to the restrictions below, The MathWorks, Inc. ("MathWorks") hereby grants to you, whether you are an individual or an entity, a license to install and use the MATLAB Runtime ("Runtime"), solely and expressly for the purpose of running software created with the MATLAB Compiler (the "Application Software"), and for no other purpose. This license is personal, nonecclusive, and nontransferable. 						
2. LICENSE RESTRICTIONS. You shall not modify or adapt the Runtime for any reason. You shall not disassemble, decompile, or reverse engineer the Runtime. You shall not alter or remove any proprietary or other legal notices on or in copies of the Runtime. Unless used to run Application Software, you shall not rent, lease, or loan the Runtime, time share the Runtime, provide service bureau use, or use the Runtime for supporting any other party's use of the Runtime. You						
Do you accept the terms of the license agreement? $\textcircled{0} \underline{Y}es \bigcirc \underline{N}\underline{o}$						
< Back Next > Cancel	📣 Ma	athWorl	CS*			

6. Click "Install."



Install MATLAB Runtime, so it will take some time.

* It takes about 10 to 30 minutes, depending on the environment.

7. Click "Finish" to end the installation.



(2) If MATLAB Runtime is already installed

- 1. Double-click SFR_Fit_v**_Installer_web.exe to start.
- 2. Click "Next".



3. Click "Next".



To create shortcuts, check the following.

Add a shortcut to the desktop

4. Click "Next."



5. Click "Install."



6. Click "Finish" to end the installation.

L Installation Complete		2 <u>-</u>		×
Installation completed successfully.				
			1	
	Finish			
	1 101311			

- 2.2 Installing CodeMeter Runtime
- 2.2.1 About Installation

CodeMeterRuntime.exe" is an installer.

- * WIBU-SYSTEMS' "CodeMeter Runtime" is a tool for license management and activation process to run software.
- 2.2.2 Installation Procedure
 - 1. Double-click "CodeMeterRuntime.exe" to start installation.
 - 2. Click "Next".

🕞 CodeMeter Runtime Kit v7.	40b Setup — \Box \times
	Welcome to the CodeMeter Runtime Kit v7.40b Setup Wizard
Contraction of the second seco	This will install CodeMeter Runtime Kit v7.40b on your computer. Click Next to continue or Cancel to exit the Setup Wizard.
	Back Next Cancel

3. Check "I accept the terms in the License Agreement" and click "Next."

😭 CodeMeter Runtime Kit v7.40b Setup	—		×
End-User License Agreement Please read the following license agreement carefully		ale de la composition de la composition Ale composition de la composition de la Ale composition de la compos	
WIBU-SYSTEMS AG, Karlsruhe, Germany and Wibu-System: Edmonds, WA, USA Software License Agreement, Single Use License CodeMeter and WibuKey Software PLEASE READ THIS SOFTWARE LICENSE AGREEMENT (" BEFORE USING THE SOFTWARE. BY USING THE SOFTW ARE AGREEING TO BE BOUND BY THE TERMS OF THIS LI YOU ARE ACCESSING THE SOFTWARE ELECTRONICALL YOUR AGREEMENT TO BE BOUND BY THE TERMS OF THI BY CLICKING THE "AGREE/ACCEPT" BUTTON. IF YOU DO TO THE TERMS OF THIS LICENSE, RETURN THE WIBU-SY I accept the terms in the License Agreement	s USA 'LICEN ARE, Y ICENS AY, SIG IS LIC D NOT 'STEM	Inc., NSE") OU E. IF NIFY ENSE AGREE IS	^
Print Back Next		Can	cel

4. Click "Next".

🙀 CodeMeter Runtime Kit v	7.40b Setup		_		×
Installation Scope Choose the installation sc	ope and folder				
User name: Organization:					
 Install just for you CodeMeter Runtime just for your user ac Install for all users 	Kit v7.40b will be i count. of this <u>m</u>achine	nstalled in a p	er-user folder and	be available	ł
CodeMeter Runtime and be available for	Kit v7.40b will be i all users. You mus	nstalled in a p t have local A	er-machine folder l dministrator privile	by default ges.	
		<u>B</u> ack	<u>N</u> ext	Cance	2

5. Click "Next".

😸 CodeMeter Runtime Kit v	7.40b Setup		—		×	
Custom Setup Select the way you want		91. 27				
Click the icons in the tree	below to change the	e way features	will be installed.			
	er Runtime Kit etwork Server /ibuShellExtensior ser Help	This features installs the CodeMeter Runtime Kit on your computer.				
A R	utomatic server s emote access to \	This feature r drive. It has 3 The subfeatur hard drive.	your hard s selected. on your			
				Browse		
Reget	Disk <u>U</u> sage	<u>B</u> ack	<u>N</u> ext	Cance	I	

6. Click "Install".



7. Click "Finish" to finish the installation.



3. License Activation

3.1 About License

The license Ticket ID will be sent by email. Use the Ticket ID mentioned in the email to activate the license. To perform the activation, click on the URL provided in the same email to access WebDepot.

3.2 Activation Method for Online PC

3.2.1 Activation Processing



3.2.2 New License

- 1. Copy the ticket ID provided in the email.
- 2. Click the URL of the "WebDepot" website for performing the activation process, as provided in the email.
- 3. "WebDepot" will be displayed in your internet browser.

CodeMeter License Central We: × +						0 ×
← → C 😫 Ic.codemeter.com/94817/depot/index.php				■ ☆	Ð	÷ :
	Leader	English	*			
	Home Auto Update					
	Welcome to CodeMeter License Central WebDepot					
	Welcome to CodeMeter License Central WebDepot. You can transfer your licenses to your Cm WebDepot. Please enter your ticket and click "Next".	Container using this				
	Ticket:					
	Next					
	© Leader Electronics Corporation					
	Legal Notice CodeMeter License Central WebDepot v21.04a.276.501.ws4					

4. Enter the Ticket ID and click "Next".

CodeMeter License Central Wit: *						o ×
← → C (11 lc.codemeter.com/94817/depot/index.php				間 ☆	Ð	⊕ E
	Leader	English	₩			
	Home Auto Update					
	Welcome to CodeMeter License Central WebDepot					
	Welcome to CodeMeter License Central WebDepot. You can transfer your licenses to your Cm0 WebDepot. Please enter your ticket and click "Next".	Container using this				
	Ticket: T86UW-LYXJF-MT56J-HABKW-PWIKC5					
	Next					
	C Leader Electronics Corporation					
	Legal Notice CodeMeter License Central WebDepot v21.04a.276.501.ws4					

3. License Activation

5. "My Licenses" will be displayed. Click "Activate Licenses".

CooleMeter License Central Vic. × +									9 ×
← → ♂ Its Ic.codemeter.com/94817/depot/oveniew.php							■ ☆	Ð	\$:
	Leader				English	8			
	Home My Licenses								
	My Licenses								
	Name		Activated On	CmContainer	Status				
	SFR-Fit Software License				Available				
	Activate Licenses								
	© Leader Electronics Corpor	ration							
	Legal Notice CodeMeter Li	cense Central WebDe	epot v21.04a.276.501.ws4						

"Available Licenses" will be displayed. Click "Activate Selected License Now".

* When activating a new license, since CmContainer is not created on the PC, you can only choose to automatically obtain CmContainer. For PCs where activation has been performed before, the serial number of the CmContainer will be displayed.

CodeMeter License Central Wei X +					0 ×
€ → Ø 🖾 Ic.codemeter.com/94817/depot/get.php			88 ☆	Ð	₽ :
	Leader	English 🗃 🗷			
	Home My Licenses				
	Available Licenses				
	To activate your licenses: 1. slate the locense you need to activate. 2. slate the locence yournoted or Orchotene to which you want to transfer the locenses. 3. Click "Activate Selected Licenses New".				
	R Name Activated On CmContainer	Status			
	SFR-Fit Software License -	Available			
	Select CmContainer Cet CmContainer automatically • [2] Activate Selected Lecences Now I My Licenses	File-based license transfer			
	© Leader Electronics Corporation				
	Legal Notice CodeMeter License Central WebDepot v21.04a.276.501.ws4				

6. The activation process (Online License Transfer) will begin.

*Please wait a moment. It may take a few seconds for the process to complete. Do not remove the CmContainer or reload the page until the process is finished.

CodeMeter License Central Wei × +				- 0 ×
← → C 😫 k.codemeter.com/94817/depot/assignedLicense	php			월 ☆ D 호 🕀 E
	Leader	under .	English 📾 💌	
	Available Automat To transfer your aut I. Make sure that the not connected to th	with The selected licenses are transferred. This may take several minutes to complete. Rease move the Crifforstater during this process and load this page.	f bis CmContainer is	
	Name SFR FK Software Licer Bit R FK Software Licer Bit	rafes: junst. e update.	Status Auto Update File-based license transfer	
	Lagal Notce CodeNeter Leanse Central Web	Depet v21.04a.276.501.we4		

7. "License transfer completed successfully!" will be displayed. Click "OK".

CodeMeter license Central Wei X +			- 0 X
€ → Ø 🛱 Ic.codemeter.com/94817/depot/assignedLicenses.php			월 ☆ 12 🚔 8
Lead	der	English 🗱 🗑	
Home	My Licenses Online License Transfer		
Available	Automat Starting license transfer. Creating license request.		
To transfi 1. Make s not con 2. Clek T	er yaar aut moorting license update to CmContainer. Creating receipt. Uploading receipt.	f this CmContainer is	
E. GROK	License transfer completed successfully!		
Name	_	Status	
SFR-Fit Soft sine in soft	tware Licen Aware sizerae	Auto Update	
Transfer			
() Leader Ele			
Legal Notice			

3. License Activation

8. The activation date and time, along with the serial number of the CmContainer, will be displayed.

CodeMeter License Central Wei × +						- 0	×
← → ♂ (11 Ic.codemeter.com/94817/depot/oveniew.php					■ ☆	Ð I 🤤) :
	Leader		E	nglish 🗮 💌			
	Home My Licenses						
	My Licenses						
	Namo	Activated On	CmContainer	Status			
	SFR-Fit Software License	2024-06-11 15:21:32	130-3825618762	Activated			
	© Leader Electronics Corporation						
	Legal Notice CodeMeter License Ce	ntral WebDepot v21.04a.276.501.ws					

3.2.3 Updated License

- 1. Copy the Tcket ID provided in the email.
- 2. Click the URL of the WebDepot website for performing the activation process, as provided in the email.
- 3. "WebDepot" will be displayed in your internet browser.

CodeMeter License Central Wei × +						- 0	0 X
← → C 😫 Ic.codemeter.com/94817/depot/index.php		5-51		20	☆	Ð	₽ :
	Leader	English	*				
	Home Auto Update						
	Welcome to CodeMeter License Central WebDepot						
	Welcome to CodeMeter License Central WebDepot. You can transfer your licenses to your Cm6 WebDepot. Please enter your ticket and click "Next".	Container using this					
	Ticket:						
	Next						
	© Leader Electronics Corporation						
	Legal Notice CodeMeter License Central WebDepot v21.04a.276.501.ws4						

4. Enter the Ticket ID and click "Next".

CodeMeter License Central Write X +						o x
← → C 🛱 Ic.codemeter.com/94817/depot/index.php				₿ ☆	5	÷ :
	Leader	English	*			
	Home Auto Update					
	Welcome to CodeMeter License Central WebDepot					
	Welcome to CodeMeter License Central WebDepot. You can transfer your licenses to your Cm WebDepot. Please enter your ticket and click "Next".	Container using this				
	Ticket: T86UW-LYXIF-MT56J-HABKW-PWKC5					
	Next					
	© Leader Electronics Corporation					
	Legal Notice CodeMeter License Central WebDepot v21.04a.276.501.ws4					

"My Licenses" will be displayed. Click "Auto Update".
 *A strikethrough will appear on the previous license.

CodeMeter Losses Central Wei × +					- 0 X
← → Ø St k.codemeter.com/94817/depot/overview.pt	hp				新学 D 子 合:
				English 📾 💌	
	My Licenses				
	Name	Activated On	CmContainer	Status	
	SFR-Fit Software License BFR-Fit Software Science	-	© 130-1789614573	Auto Update	
	Auto Update				
	© Leader Electronics Corporation				
	Legal Notice CodeMeter License	Central WebDepot v21.04a.276.5	01.ws4		

3. License Activation

6. "Available Automatic License Updates" will be displayed. Click "Transfer License Updates Now".

CodeMeter Scenes Central Wr: × +						- 0 ×	
← → C III Ic.codemeter.com/94817/depot/assignedLicens	testyb					N ☆ Ď L ± 🖨 :	
	Leader			English 🗃	×		
	Available Automatic Licens	e Updates					
	To transfer your automatic license updates to CmContainer: 1. Hale sure that the CmContainer with Serial 130-3825618762 is connected to this computer. If this CmContainer is not connected to this computer, connect it now and click "Rescan for CmContainers". 2. Click "transfer License Updates Now".						
	Name	Activated On	CmContainer	Status			
	SFR-Fit Software License	- 2024 05-11-15-21-32	130-3825618762	Auto Update			
	Transfer License Updates Now			File-based license tra	nsfer		
	C Leader Electronics Corporation						
	Legal Notice CodeMeter License Ce	entral WebDepot v21.04a.276.	501.ws4				

7. The activation process (Online License Transfer) will begin.

*Please wait a moment. It may take a few seconds for the process to complete. Do not remove the CmContainer or reload the page until the process is finished.

CodeMeter Scener Central Wei X +				- 0 ×
€ → σ 🖽 k.codemeter.com/94817/depot/assignedLicenses.p	hp			N X D L 🖨 !
	Leader		English 😹 🖬	
	Home My Licenses Online	License Transfer		
,	Available Automat	Please wait! The selected licenses are transferred. This process may take several minutes to complete. Please		
	Make sure that the not connected to th Click "Transfer Lice	do not remove the CmContainer during this process and do not reload this page.	f this CmContainer is	
	Name Starting	j license transfer. J license request. action license undate	Status	
	SFR-Fit Software Licent	and of the second control operation	Auto Update	

8. "License transfer completed successfully!" will be displayed. Click "OK".

CodeMeter License Central Wei × +			- 0 ×
← → Ø It Ic.codemeter.com/94817/depot/assignedLicenses	styb	1	\$0 ☆ Ď L ± ⊕ :
	Leader	English 800 💌	
	Available Automs Sector request Descent request Available Automs Descent request Descent request Available Control Container Control Control Container Control Control Container Control Cont	t the CreContainer Is Status Auto Update	
	Legal Notce Coddfeter Licons Central WebDepct v21.048.276.301.ws4		

9. The activation date and time, along with the serial number of the CmContainer, will be displayed.

	CodeMeter License Cen	etral Wei × +					- 0
€ →	C S Iccode	emeter.com/94817/depot/oveniew.p	php				भ x D 4
			leader		Engli	ish 🗮 🖬	
			Leover				
			Home My Licenses				
			My Licenses				
			Name	Activated On	CmContainer	Status	
			SFR-Fit Software License	2024-06-11 15:21:32	• 130-3825618762	Activated	
			© Leader Electronics Corporation	n			
			Level Notice CodeMater License	e Central WebDenot v21 04a 276 501	wed		

3.2.4 License Cancellation

- 1. Copy the Ticket ID provided in the email.
- 2. Click the URL of the WebDepot website for performing the activation process, as provided in the email.
- 3. "WebDepot" will be displayed in your internet browser.

CosteMeter License Central We: × +						0 ×
← → C 😫 lc.codemeter.com/94817/depot/index.php				8₀ ☆	Ð	⊕ ∃
	Leader	English	8			
	Home Auto Update					
	Welcome to CodeMeter License Central WebDepot					
	Welcome to CodeMeter License Central WebDepot. You can transfer your licenses to your Cm WebDepot. Please enter your ticket and click "Next".	Container using this				
	Ticket:					
	Next					
	C Leader Electronics Corporation					
	Legal Notice CodeMeter License Central WebDepot v21.04a.276.501.ws4					

4. Enter the Ticket ID and click "Next".

• • • • • • • • • • • • • • • • • • •	CodeMeter License Central Wei * +					- 0	×
Internet And Lighting Internet And Lighting Concentration of Control Methodopool, You can transfer your Concontainer using thes subjects. Please enter your State and cick "Next". Control Technology Control Methodopool you can transfer your Concontainer using thes subjects. Please enter your State and cick "Next". Control Technology Control Methodopool you can transfer your Lineare State and Cick "Next". Control Technology Control Methodopool you can transfer your Lineare State and Cick "Next". Control Technology Control Methodopool you can transfer your Lineare State and Cick "Next".	← → ♂ ti lc.codemeter.com/94817/depot/index.php				¶0 ☆	014	1
tems Auto Update Welcome to CodeMeter License Central WebDepot Welcome to CodeMeter License Central WebDepot, You can transfer your licenses to your CmContainer using the WebDepot, Please enter your ticket and click "Next". Tester: Tester: Tester: Next Next Next Next Next Next Next Next Next Next Next		Leader	English	B			
Welcome to CodeMeter License Central WebDepot. WebDepot. Please enter your tooks and clock "Next". Tetrue-V-CM-MTSD-Mulacov-Provoccs Instr WebDepot. Please enter your tooks and clock "Next". Note: WebDepot. Please enter your tooks and clock "Next". Note: Device Dectores: Componition Legial Notice CodeMeter License Central WebDepot v21.04s.276.501.wsl.		Home Auto Update					
Welcome to CodeMeter Learne Cartrol WelCopot. You can transfer your learnes to your OnContainer using this WelCopot. Please entiry your Scient and disk "Next". Not © Leader Electrones: Corporation Legial Notice CodeMeter Learner Central WelCopot v21.04s.276.501.vpd		Welcome to CodeMeter License Central WebDepot					
Ticket: Ticket: Not O Leader Electronics Corporation Legal Notice Cobabilitier License Control WebDopst v21.04s.276.501.ws4		Welcome to CodeMeter License Central WebDepot. You can transfer your licenses to your Cmi WebDepot. Please enter your ticket and click "Next".	Container using this				
© Lender Electrones Corporation Legal Notice CodeNeter License Central WebOopot v21.04s.376.501.ws4		Ticket: TB6UW-LYKJF-MT563-HABKW-PWKC5 Not					
Legal Notce CodeMeter Leenon Cantral WebDepot v21.04a.276.501.ws4		© Leader Electronics Corporation					
		Legal Notice CodeMeter License Central WebDepot v21.04a.276.501.ws4					

"My Licenses" will be displayed. Click "Auto Update".
 *A strikethrough will appear on the previous license.

CodeMeter License Central We × +						0 X
← → ♂ Is locodemeter.com/94817/depot/overview.php					\$i ☆ D	표 🖨 :
	Leader		Enj	glish I		
	Home My Licenses					
	My Licenses					
	Name A	ctivated On	CmContainer	Status		
	SFR-Fit Software License	2024-08-12-15/22-02	130-3825618762	Auto Update		
	Auto Update					
	© Leader Electronics Corporation					
	Legal Notice CodeMeter License Central	WebDepot v21.04a.276.501.ws	4			

6. "Available Automatic License Updates" will be displayed. Click "Transfer License Updates Now".

CodeMeter Sicense Central Wei × +						- 0 ×
← → C 😫 k.codemeter.com/94817/depot/assignedLicens	esphp				te ☆ D	± 🖨 :
	Leader Home My Licenses			English 📾 💌		
	Available Automatic Licens	e Updates				
	To transfer your automatic lice 1. Make sure that the CmContain not connected to this compute 2. Click "Transfer License Updates	nse updates to CmContainer: er with Serial 130-3825618762 r, connect it now and click "Resca Now".	is connected to this computer n for CmContainers*.	r. If this CmContainer is		
	Name	Activated On	CmContainer	Status		
	SFR-Fit Software License	2024-06-11 16:07:27	 130-3825618762 	Auto Update		
	Transfer License Updates Now			File-based license transfer		
	© Leader Electronics Corporation					
	Legal Notice CodeMeter License Co	entral WebDepot v21.04a.276.50	L.ws4			

7. The activation process (Online License Transfer) will begin

*Please wait a moment. It may take a few seconds for the process to complete. Do not remove the CmContainer or reload the page until the process is finished.

CodeMeter License Central Weit +		- 0 ×
€ → σ 🕮 k.codemeter.com/94817/depot/assignedLicenser	крр	월 ☆ 12 년 🖨 1
	Leader Hence My Leanes Transfer	
	Available Astrona Piece with The addend homes an transfer. Tatmar year at 1 Mar and the to be conserved with the 2 Cash Theories and Camera Piece with The addend homes an transfer. Tatmar year at 1 Mar and the to be conserved with the conserved with the process and do not reload this page. Piece with the process and do not reload this page. Tatmar year at 1 Mar at the served with the conserved with the process and do not reload this page. Ethic Directoritainer is Catering location theories. Tatmar year at the conserved with the process at the conserved with the process and do not reload this page. Ethic Directoritainer is Catering location theories. Tatmar year at the conserved with the process at the conserved with the process and do not reload this page. Ethic Directoritainer is Catering location theories. Tatmar year at the conserved with the process at the conserved with the process at the conserved with the process and do not reload the page. Ethic Directoritainer is Catering location theories. Tatmar year at the conserved with the process at the conserved with the process at the page. Ethic Directoritainer is Catering location theories. Tatmar year at the conserved with the page. Ethic Directoritainer is Catering location theories. Ethic Directoritainer is Catering location theories. Tatmar year at the conserved with the page. Ethic Directoritainer is Catering location theories. Ethic Directoritainer is Catering location theories.	
	Legal Notice CodeMeter License Carihal WebDepot v21.646.376.501.eest	

8. "License transfer completed" will be displayed. Click "OK".



9. Confirm that the license has been canceled. *[See "4. License Confirmation"]

3.2.5 License Transfer to Another PC

- 1. Perform various installations on the destination PC. [See "2. Installation"].
- 2. Cancel the license on the original PC. [See "3.2.4 License Cancellation"]
- 3. Activate the license on the destination PC. [See "3.2.1 New License"]

3.3 Activation Method for Offline PC

When this software is installed on an offline PC, license activation requires transferring several files through an online PC.

3.3.1 Activation Processing



3.3.2 New License

- 1. Copy the Ticket ID provided in the email.
- 2. Click the URL of the "WebDepot" website for performing the activation process, as provided in the email.
- 3. "WebDepot" will be displayed in your internet browser.
- 4. Enter the Ticket ID and click "Next".

CosteMeter License Central We: +							o x
← → ♂ 🛱 lc.codemeter.com/94817/depot/index.php				8	☆	Ð	- :
	Leader	English	35 ¥				
	Home Auto Update						
	Welcome to CodeMeter License Central WebDepot						
	Welcome to CodeMeter License Central WebDepot. You can transfer your licenses to your On WebDepot. Please enter your ticket and click "Next".	Container using this					
	Ticket:						
	Next						
	© Leader Electronics Corporation						
	Legal Notice CodeMeter License Central WebDepot v21.04a.276.501.ws4						

3. License Activation

CodeMeter Limss Central Wit: + + + + + C 2 2; Is codemeter.com/94817/depat/index.php				副会	-	0 X
	Leader	English	田 田			
	Home AutoUpdate Welcome to CodeMeter License Central WebDepot					
	Welcome to CodeMeter License Central WebDepot. You can transfer your licenses to your Cm WebDepot. Please enter your ticket and click "Next".	nContainer using this				
	Ticket: T86U/W-LYCIF-MT56J-HABKW-PWKC5 Not					
	© Leader Electronics Corporation					
	Legal Notice CodeMeter License Central WebDepot v21.04a.276.501.ws4					

5. "My Licenses" will be displayed. Click "Activate Licenses".

CosleMeter Dornse Central Wol							- σ ×
$ \label{eq:complexity} \leftarrow \ \ \rightarrow \ \ \ \ \ \ \ \ \ \ \$						■ ☆	0 🌒 i
	Leader			English	*		
	Home My Licenses						
	My Licenses						
	Name	Activated On	CmContainer	Status			
	SFR-Fit Software License	-		Available			
	Activate Licenses						
	© Leader Electronics Corporation						
	Legal Notice CodeMeter License Central Web	Depot v21.04a.276.501.ws4					

6. Available Licenses" will be displayed. Click "File-based license transfer" at the bottom right.

* When activating a new license, since CmContainer is not created on the PC, you can only choose to automatically obtain CmContainer. For PCs where activation has been performed before, the serial number of the CmContainer will be displayed.

→ Ø S Ic.codemeter.com/94817/depot/get.php			\$€ ☆	;
	Leader	English 👪 💌		
	Home My Licenses			
	Available Licenses			
	To activate your licenses: 1. Select the licenses you want to activate. 2. Select the locally convected OnContainer to which you want to transfer the licenses. 3. Click "Activate Selected Licenses New".			
	Name Activated On CmCentainer SFR-Fit Software License -	Status Available		
	Select CmContainer Get CmContainer automatically = 0			
	Activate Selected Licenses Now	File-based license transfer		
	My Licenses			
	© Leader Electronics Corporation			
	Level Natice CodeMeter Licence Control WebDendt v21 045 225 501 ws4			

7. Click the "+" next to "Operation Description" within the white frame.

CodeMeter Learner Central Wey +			- 0
€ → Ø 🗐 k.codemeter.com/94817/depot/get.php			¥ ★ D - €
	Leader English		
	Available Licenses		
	Upload Receipt Upload Receipt		
	To activate your licenses with the transfer - Inst step "Oplied Request": If you have studied increase from the license increase state in the same Criciontene(s). If you want to use another Criciontene, you need a license request file of this new CricContainer 1. Select an already used CricIontener or reade a license request file with Firm Code 6000010 for the CricIontain i works to be transfer to the same to activate. 2. Select the overagin used to activate. 3. Click "Continue".	er forv	
	Name Activated On CmContainer Status		
	SFR-Fit Software License - Available		
	Select an already used CmContainer No CmContainer foundi *		
	or		
	Pick a license request file (*.WibuCmRaC) of another CmContainer ファイルを選択 (選択されていません)		
	Start Activation New Direct license	transfer	
	My Licenses		
	© Leader Electronics Corporation		

8. The explanation text within the white frame will expand. Click "Download template now" in section "b". A License Information File (.WibuCmLIF) will be generated in the download folder.

On the online PC, save the License Information File (.WibuCmLIF) to a USB memory stick, then remove the USB memory stick.

CodeMeter License Central We: × +				
→ Ø S lc.codemeter.com/94817/depot/get.php				≅ ☆ D
	Upload Request	Download Update	Upload Receipt	
	To activate your licenses via file transfer - F	First step "Upload Request":		
	If you have activated licenses from this ticket al CmContainer(s). If you want to use another Cm	already, you can transfer additional licenses mContainer, you need a license request file	into the same of this new CmContainer.	
	Select an already used Chr.Container or create where you want to transfer the konness to. 1 it works B Safe CodeReter Centrel Center on the cor- text code and the container of a Chr.Container contained templot around contained templot ar	de a liconar request file with Firm Code 40 the file can for example be credet with or mputer where the desired OmContainer is, and the program of the computer of the states by designed the download for the to download for the computer, file, a file, a file, a file, b of orested to this computer.	000016 for the CimContainer deMeter Control Center. How woldad a template here: odeMeter Control Center. equest":	
	SFR-Fit Software License	Activated On CmContaine	Available	
	Select an already used CmContainer No CmContainer found! ¥ or			
	Pick a license request file (*.WibuCmRaC) of a	another CmContainer		
	ファイルを選択 選択されていません			
	Start Activation Now		Direct license transfer	
	My Licenses			

9. Connect the USB memory stick to the offline PC. From the desktop, click "Start" then select "CodeMeter" to launch the "CodeMeter Control Center".

Drag and drop the License Information File (.WibuCmLIF) from the USB memory stick into the "CodeMeter Control Center" to import it.

S CodeMeter Control Center	-		×
File Process View Help			
License Events			
No CodeMeter License information available. No ConContainer found.			
CodeMeter service has been stopped.		Web Ac	lmin

10. " Import of CmActLicense Firm Item template was successful." will be displayed. Click "OK".

CodeMeter Control Center		-		\times
File Process View Help				
License Events				
	No CodeMeter License information available. No OmContainer found. CodeMeter ? × Information: Import of CmActLicense Firm Item template was successful.			
CodeMeter service has been stopped.			WebA	łdmin

11. Click "License Update ".

S CodeMeter Control Center		-		×
File Process View Help				
License Events				
Leader Software Licence (Firm 130-780487055	Name: Leader Software License (Firm Code 6000010) Serial: 130-780487055 Version: CmActlicense: 800			
	Status: 🎯 Empty license container			
	Licence Update Remove Licence			
CodeMeter service is running.			Web A	dmin

12. Click "Next >".

	?	×
← ⓒ CmFAS Assistant		
Welcome to the CmFAS Assistant!		
The CodeMeter Field Activation Service (CmFAS) assistant helps you adding, chang deleting licenses from the license management system CodeMeter.	ing and	
With the CmFAS assistant you can create license request files, which you can send of the software by email. You can also import the received license update files with assistant into the license management and create a receipt of the import for the ver	to the v the CmF dor.	endor AS
Next >	Help	•

13. Check "Create license request" and click "Next >".



14. Click "..." to set the output destination of the License Request File (.WibuCmRaC) to the USB memory stick. Then, click "Commit" to save.

		?	×
←	CmFAS Assistant		
P	Please select the file name		
C	C:¥Users¥localuser¥ 130-780487055.WibuCmRaC		
ř	Pelect a file name for storing the license request file. Then click on commit to creat	e the fil	le.
	Commit	Help	

15. Click "Finish" and then remove the USB memory stick from the offline PC.



 Connect the USB memory stick to the online PC. Click "Select File" and choose the License Request File (.WibuCmRaC) from the USB memory stick. Click "Start Activation Now".

CodeMeter License Central Wei \star 🔸				
C 15 Ic.codemeter.com/94817/depot/get.php			■ ☆	Ð
	Upload Request Download Update U	Jpload Receipt		
	To activate your licenses via file transfer - First step "Upload Request":			
	If you have activated licenses from this ticket already, you can transfer additional licenses into the	e same		
	CmContainer(s). If you want to use another CmContainer, you need a license request file of this r	new CmContainer.		
	1. Select an already used CmContainer or create a license request file with Firm Code 6000010	for the CmContainer		
	where you want to transfer the licenses to. This file can for example be created with CodeMete	er Control Center. How		
	 a. Start CodeMeter Control Center on the computer where the desired CmContainer is. 			
	b. Select this CmContainer. If no CmContainer is present on that computer, you can download	a template here:		
	Download template now. Import this template by dragging the downloaded file to CodeMete	er Control Center.		
	d. Follow the instructions of the "CmFAS Assistant". Choose the option "Create license request".			
	e. Choose a filename for the license request file.			
	 Click "Commit" to save the license request file. Transfer the license request file that you just created to this computer. 			
	Select the licenses you want to activate.			
	 Select the created license request file. 			
	4. Click "Continue".			
	Name Activated On CmContainer	Status		
	SFR-Fit Software License -	Available		
	Select an already used CmContainer			
	No CmContainer found! ~			
	01			
	51 51			
	Pick a license reguest file (*.WibuCmRaC) of another CmContainer			
	ファイルを選択 朝されていません			
	Start Activation Now	Direct license transfer		
	My Licenses			

17. Click "Download License Update File Now". A License Update File (.WibuCmRaU) will be generated in the download folder. Save the License Update File (.WibuCmRaU) to the USB memory stick and then remove the USB memory stick.



18. Connect the USB memory stick to the offline PC. From the desktop, click "Start" then select "CodeMeter" to launch the "CodeMeter Control Center". Click "License Update".

S CodeMeter Control Center	-		×
File Process View Help			
License Events			
Leader Software License (Firm 130-780487055 Name: Leader Software License (Firm Coder8000010) Serial: 100-780487055 Version: CmActLicense 3.00			
Status: C Empty license container			
CodeMeter service is running.		WebA	Admin

19. Click "Next >".

	?	\times
← S CmFAS Assistant		
Welcome to the CmFAS Assistant!		
The CodeMeter Field Activation Service (CmFAS) assistant helps you adding, chang deleting licenses from the license management system CodeMeter.	sing and	
With the CmFAS assistant you can create license request files, which you can send of the software by email. You can also import the received license update files with assistant into the license management and create a receipt of the import for the ve	i to the v the CmF ndor.	vendor FAS
Next >	Help	p

20. Check "Import license update" and click "Next >".

		Ĩ	? X
← 😋 CmFAS Assistant			
Please select the d	sired action		
🔵 Create license re	uest		
Choose this option if vendor of the softwa	you want to create a license re a.	equest file in order to send it to) the
💽 Import license up	ate		
Choose this option, it import this file.	you received a license update	file from the software vendor a	and want to
🔵 Create receipt			
Choose this option if the software vendor.	you want to confirm the succe:	ssful import of a license update	e file for
		Next >	Help

21. Click "..." to select the License Update File (.WibuCmRaU) from the USB memory stick, then click "Commit".



22. " Import Update successful." will be displayed. Click "OK".

			?	×
←	😋 CmFAS As	sistant		
	Please select	the file name		
	😋 CodeMeter	. ? ×	WibuCmRaU	
	i	Information: Import Update successful.	∍ is stored on your computer. Then click on	
		ОК		
			Commit Help	5

23. Click "Finish".

	?	×
← ⓒ CmFAS Assistant		
The license update has been successfully imported.		
You will find details for the imported licenses in the CodeMeter WebAdmin. In ord receipt for the vendor please click <u>here</u> .	ler to crea	te a
Finish	Не	lp

24. Confirm that the "Status" shows "License activated.". Click "License Update".

CodeMeter Control Center		_		×
File Process View Help				
License Events				
Leader Software License (Firm 130-3825618762	Name: Leader Software License (Firm Code 8000010) Serial: 130-3826619762 Version: CmActLicense: 3:00			
CodeMeter service is running.			Web Ac	dmin

25. Click "Next >".

	?	\times
← S CmFAS Assistant		
Welcome to the CmFAS Assistant!		
The CodeMeter Field Activation Service (CmFAS) assistant helps you adding, chang deleting licenses from the license management system CodeMeter.	ing and	
With the CmFAS assistant you can create license request files, which you can send of the software by email. You can also import the received license update files with assistant into the license management and create a receipt of the import for the ver	to the v the Cmi idor.	rendor FAS
Next >	Hel	P

26. Check "Create receipt" and click "Next >".

	?	×
← ⓒ CmFAS Assistant		
Please select the desired action		
○ Create license request		
Choose this option if you want to create a license request file in order to se vendor of the software.	nd it to the	•
🔘 Import license update		
Choose this option, if you received a license update file from the software ve import this file.	endor and v	want to
Create receipt		
Choose this option if you want to confirm the successful import of a license the software vendor.	update file	e for
Next >	He	elp

27. Click "..." to set the output destination of the Receipt (.WibuCmRaC) to the USB memory stick. Then click "Commit" to save.

	?	×
← ⓒ CmFAS Assistant		
Please select the file name		
E:#CmContainer¥130-3825618762.WibuCmRaC		
Select a file name for storing the receipt file. Then click on 'commit' to create th then send this file to the vendor by email.	ne file. You i	ban
Commit	Не	lp 📄

28. Click "Finish" and then remove the USB memory stick from the offline PC.

	?	×
← ⓒ CmFAS Assistant		
The license receipt file has been successfully created.		
The license receipt file has been successfully created. You can send it now to the vendor of the software by email.		
Finish	He	lp 🛛

29. Connect the USB memory stick to the online PC. Click "Next".

CockMeter License Central Will X +		- 0 ×
$ \begin{tabular}{lllllllllllllllllllllllllllllllllll$		■ ☆ ① ± ⊕ i
	Leader Explain III E	
	Home My Licenses	
	Download License Update File	
	Upload Request v Download Update Upload Receipt	
	To transfer your licenses via file - Second step "Download Update";	
	 Click "Download License Update File Non" and area the file on your computer. Import this loss update file to the Concrotance with Secial 130-3035618762. This file can for example be imported with OxieMeter Control Center. How it works [] After you have successfully transferred the license update file to the CmContainer, click "Next" to confirm the license transfer. 	
	Download License Update File Now Next Direct license transfer	
	My Licenses	
	© Leader Electronics Corporation	
	Legal Notice CodeMeter License Central WebDepot v21.04a.276.501.ws4	

30. Click "Select File" and choose the "License Receipt File" from the USB memory stick. Click "Upload Receipt Now".

Image: Control water in the intervent with the intervent withe intervent with the intervent with the intervent wit	Confirm License Transfer Upload Receipt Visit Upload Receipt Nov. Visit Upload Receipt Nov. Visit Upload Receipt Receipt Visit Receipt Receipt Receipt Receipt Visit Upload R
Content Learness Update Request V Developed Request Nov? Developed Request No	Openant Openant Upload Registry
Image My Licenses Confirm Licenses Transfer Uptood Request V Deveload Update Updood Request V Deveload Update Updood Recoupt" Constrainer voors tile for Third step "Updood Recoipt": Constrainer voors tile for the Cincicctaner with starial 130-3825618762 and Firm Code 6000010. This file can for example be created with CodeHater CodeFace (Your & works @ Code the created line moder Recoing Recoing Circles - How it works @ Circle Target Recoing Provide Recoing Provide Recoing Circles - How it works @ Circle Circles Recoing Provide Recoing Provide Recoing Circles - How it works @ Circle Circles Recoing Provide Reco	Nome My Licenses Confirm License Transfer Upload Recupit Upload Recupit v Download Update Upload Recupit To transfer your licenses via file - Third step "Upload Receipt": . Oreste a license receipt file from the Grad-Contrainer with Sarial 130-3825618782 and Firm Code 6000010. This file and for example be created with CodeNeter Control Center. How it works [] . Click "Upload Receipt Now". . Click "Upload Receipt Now". . If you haven't imported the license update file yet, you can download it again. Click "Back" to get to the download page.
tome My Leanes Confirm License Transfer Liptod Requet * Download Update Updat Recupt To transfer your licenses via file - Third step "Upload Receipt": Che transfer your licenses via file - Third step "Upload Receipt": Che transfer with Code/step Control Certer. How it works [] Che transfer with Code/step Control Certer. How it works [] Che transfer with Code/step Control Certer. How it works [] Che transfer with Code/step Control Certer. How it works [] Che transfer with Code/step Control Certer. How it works [] Che transfer With Update Receipt Hie ("WithUnderstep") If you haven't imported the locense update file yet, you can download it agam. Cleix "Back" to get to the download page. For Invent imported the locense update file yet, you can download it agam. Cleix "Back" to get to the download page. If you haven't imported the locense update file yet, you can download it agam. Cleix "Back" to get to the download page. If you haven't imported the locense update file yet, you can download it agam. Cleix "Back" to get to the download page. If you haven't imported the locense update file yet, you can download it agam. Cleix "Back" to get to the download page. If you haven't imported the locense update file yet, you can download it agam. Cleix "Back" to get to the download page. If you haven't imported the locense update file yet, you can download it agam. Cleix "Back" to get to the download page. If you haven't imported the locense update file yet, you can download it agam. Cleix "Back" to get to the download page. If you haven't imported the locense update file yet, you can downl	Home My Licenses Confirm License Transfer Uplood Request 'v Download Update Uplood Receipt To transfer your licenses via file - Third step "Upload Receipt": .
Confirm License Transfer Uption Request × Download Update Update Request Contained request is file - Third step "Upload Receipt": - On transfer your licenses via file - Third step "Upload Receipt": - One the Container words file from the Control Carter, How it works @ - One as a known encoget file from the Control Carter, How it works @ - One to carter works @ - One as a known encoget file from the Control Carter, How it works @ - One to carter works @ - One as works @ - One to carter works @ - One to carter works @ - One to carter works @ - One to carter works @ - One to carter works @ - One to carter works @ - One to carter works @ - Diverse Wite Carter - One to carter works @ - One to carter works @ - One to carter works @	Confirm License Transfer Upload Request v Upload Receipt* To transfer your licenses via file - Third step "Upload Receipt*: Contra E license receipt file - Third step "Upload Receipt*: Contra E license receipt file - Third step "Upload Receipt*: Contra E license receipt file from the OnContranse with Seciel 130-9.935618762 and Firm Code 6000010. This file and for another second file license receipt file. Secient Contract Control Contro
Upbood Request v Deveload Upbote Upbood To transfer your licenses vis file - Third step "Upboad Receipt": . 1. Owahr a locan receipt file from the Cond-baser with Serial 103 2035/15/3763 and Firm Code 6000010. This file can for example be created with Code/baser costs of with a costs of . 2. Okak 'Tupbod Receipt Now". . 3. Okak 'Tupbod Receipt Now". . 1. You haven't imported the locanse update file yet, you can download it again. Click "Back" to get to the download page. Pick License receipt file ('.WibuGmRacC) 2. You Ale at III 'II' 0-3023634782.WbuCmRacC Vibud Receipt Now" Table Vibud Receipt Now Detect license transfer Output Outp	Upload Request v Download Update Upload Receipt To transfer your licenses via file - Third step "Upload Receipt": . Control Exercise The From the ConContainer with Saird 120-32354.8762 and Firm Code 6000010. This file can for example be created with CodeMeter Control Center. How it works at a control Select the created license receipt file. 2. Select the created license receipt file. . Click "Upload Receipt Nov". If you haven't imported the license update file yet, you can download it again. Click "Back" to get to the download page.
Upped weigher * Deminder Oppose Demonstration To transfer your licenses via file - Third step "Uppled Raccight":	Opend request Developed Developed Developed To transfer your licenses via file - Third step "Upbed Receipt": 1. Orste a license receipt file - Third step "Upbed Receipt": 1. Orste a license receipt file from the CircContainer with Serial 130-3825618762 and Firm Code 6000010. This file can for sample be costed with CodeNeter Control Center. How it works g 2. 2. Cick. "Upbed Receipt Nov." If you haven't imported the license update file yet, you can download it again. Cick "Back" to get to the download page.
	To transfer your licenses via file - Third step "Upload Receipt": 1. Create a license receipt file from the CmContainer with Serial 130-3825618762 and Firm Code 6000010. This file can for example be created with CodeMeder Control Center. How it works [] 2. Select the created license receipt file. 3. Click "Upload faceopt Now". If you haven't imported the license update file yet, you can download it again. Click "Back" to get to the download page.
1. Create a locarson recercipt file from the Circitochemien with Seriel J30-32354812962 and Firm Code 6000010. This file a for resardle locarson for the Circitochemic Provide Circitochemic	 Create a license receipt file from the CmContainer with Serial 130-3825618762 and Firm Code 6000010. This file can for example be created with CodeHeder Control Center. How it works [] Select the created license receipt file. Click "Updated ficence thow". Click "Updated ficence thow". If you haven't imported the license update file yet, you can download it again. Click "Back" to get to the download page.
a land of example do cleaned with a land of example do cleaned with a land of example do cleaned with a land of example down receiver the b land of example down receiver the b land of example down relation b land of examp	can for example be created with CoderVeter Coditor Center new it works a 2. Select the created license receipt file 3. Click "Updad Receipt Now". If you haven't imported the license update file yet, you can download it again. Click "Back" to get to the download page.
3. Clear "Updad Recent New": If you haven't imported the locence update file yet, you can download it again. Click "Back" to get to the download page. Pick license receipt file (*.WibuchRacC) Pick relation to 10-10236/8782.WibuchRacC Updad Recent New Direct license Direct license	 Circk "Upback Receipt Nov". If you haven't imported the license update file yet, you can download it again. Click "Back" to get to the download page.
If you haven't imported the locense update file yet, you can download it again. Click "Back" to get to the download page. Pick license receipt file (".WitkuCmRacC) P27241,8 #kit 0.0-382541762.WitkuCmRac Update Receipt Rev Direct license transfer M Licenses	If you haven't imported the license update file yet, you can download it again. Click "Back" to get to the download page.
Pick license receipt file (* MikaCmRaC) 27 # / L/# Rit 39-382561876.2 WebuCmRaC Uplead Receipt New Back Direct license transfer II My Licenses	
Uplead Receipt New Back Direct license transfer Image: Comparison of the second secon	Pick license receipt file (*.WibuCmRaC)
Uplead Receipt New Back Direct license transfer	ファイルを連訳 30-3825618762.WibuCmRaC
My Lonnes	Upload Receipt New Back Direct Icense transfer
 It is the first first second or 	Multiverses
A London Clashennian Companyian	
	C Leader Electronics Corporation
Legal Notice CodeMeter License Central WebDepot v21.04a.276.501.ws4	

3. License Activation

31. "License transfer completed successfully." will be displayed. Click "OK". The activation of the new license is now complete.

CodeMeter License Central We: × +					0 X
← → ♂ 🛱 lc.codemeter.com/94817/depot/confirmation.pl	qr			\$e ★ 12	± 🗣 :
	Leader	English	8 D		
	Home My Licenses				
	License Transfer Successfully Completed				
	The license transfer has been completed successfully.				
	ОК				
	© Leader Electronics Corporation				
	Legal Notice CodeMeter License Central WebDepot v21.04a.276.501.ws4				

3.3.3 Updated License

- 1. On the online PC, copy the Ticket ID provided in the email.
- 2. Click the URL of the "WebDepot" website for performing the activation process, as provided in the email.
- 3. "WebDepot" will be displayed in your internet browser.

CodeMeter Dicense Central Wei × +						- 0	×
← → ♂ tt lc.codemeter.com/94817/depot/index.php				8	* 1	0 (. :
	Leader	English	38 💌				
	Home Auto Update						
	Welcome to CodeMeter License Central WebDepot						
	Welcome to CodeMeter License Central WebDepot. You can transfer your licenses to your Cmk WebDepot. Please enter your ticket and click "Next".	Container using this					
	Ticket:						
	Next						
	© Leader Electronics Corporation						
	Legal Notice CodeMeter License Central WebDepot v21.04a.276.501.ws4						

4. Enter the Ticket ID and click "Next".

CodeMeter License Central Write +						o ×
← → C 🛱 Ic.codemeter.com/94817/depot/index.php				¤ () ☆	Ð	₽ ∃
Leader		English B	*			
Home Auto Update						
Welcome to CodeMeter License Central WebD	lepot					
Welcome to CodeMeter License Central WebDepot. You car WebDepot. Please enter your tacket and click "Nest".	n transfer your licenses to your Cmi	Container using this				
Ticket: Tesuw-LykJF-MT56J-HABKW-PWKC5						
Next						
© Leader Electronics Corporation						
Legal Notice CodeMeter License Central WebDepot v21.04a	.276.501.ws4					

"My Licenses" will be displayed. Click "Auto Update".
 *A strikethrough will appear on the previous license.

CodeMeter Greece Central We × +								o ×
← → ♂ (≒ lc codemeter com/94817/depot/overview.php						≊ ∃ ☆	0.	± 🖨 :
				English 📾 🖼				
	My Licenses				12			
	Name	Activated On	CmContainer	Status				
	SFR-Fit Software License grin / in Software License	- 2024-08-12-17528-29	© 130-1789614573	Auto Update				
	Auto Update							
	Leader Electronics Corporation							
	Legal Notice CodeMeter License Contr	al WebDepot v21.04a.276.501.	asi					

6. "Available Automatic License Updates" will be displayed. Click "Offline License Transfer" at the bottom right.

*Since the online PC does not have the "CmContainer" required for license activation, an error message will be displayed.

CodeMeter License Central We * *							- 0 ×
← → ♂ C II (c.codemeter.com/94817/depot/assignedLicense	s.php					\$ 1 ☆ D	± ⊕ :
				English 🚳 💌			
	Available Automatic License	Updates					
	To transfer your automatic licens 1. Make sure that the CmContainer not connected to this computer, o 2. Click "Transfer License Updates N	e updates to CmContainer: with Serial 130-1789614573 connect it now and click "Rescar low".	is connected to this comput for CmContainers".	ter. If this CmContainer is			
	Name	Activated On	CmContainer	Status			
	SFR-Fit Software License	- 2024-06-11-17:20:19	130-1789614573	Auto Update			
	Error The CmContainer with senal license transfer. Oct 808810E CodeMeter License Central V 2024-06-11 07:40:19 (UTC	130-1789614573 was not four VebDepot v21.04a.276.501.ws4	d. Please connect it to you	r PC or use file-based			
	Rescan for CmContainers			File-based license transf	er		
	C Leader Electronics Corporation						
	Legal Notice CodeMeter License Cent	ral WebDepot v21.04a.276.501	.ws4				

7. "License Auto Update" will be displayed.

 ✓ 🐳 sh-dt-v122 (〒10/2-8) → (3) - × - M BBH(-1)(11) - mchileour 	eki0) × 10月-デー電子性式会社 - 11/0デー × 0 ChetGPT	× CodeMeterLiceope Cer	test Wir X +		- 0 ×
← → C (≒ kccodemeter.com/94817/depot/autoUpdate.pf	hp			b i ☆	D ₹ .
🔇 육니/97 📍 0%72 - 795-11-87. 🖙 Yahool JAPAN 🖌 Eshibitor M	ny Pager (📓 ANIS Skill Builder 🛛 Leader Company: Z 😒 739F	ならアマリンウ 🏘 GLADIAS 🏘 GLADIAS test 🧍	🛊 GLADIAS — WordP 🚯 GLADIAS QC Admin 🚯 G	ADIAS-local 😅 SAP Business ByDes	» D #4767977-7
	Leader		English 🐻 💌		
	Automatic License Update				
	Velocit Augusta Welcome to automatic license update. Here you find license updates for you CreCont To check for license updates via file transfe 1. Create a license request file for the CreCont identify our CircContaine. 2. Select the created license request file. 3. Cick "Check License Updates". You can transfer these updates during the new	Downood upcase aner, provided by the vendor of the lo are are tri tri tri tri tstep.	upoas receipt		
	Pick license request file (*.WibuCmRaC)				
	ファイルを選択 選択されていません				
	Start Activation Now		Direct license transfer		
	© Leader Electronics Corporation				
	Legal Notice CodeMeter License Central WebDe	pet v21.04a.276.501.ws4			

8. Connect the USB memory stick to the offline PC. From the desktop, click "Start" then select "CodeMeter" to launch the "CodeMeter Control Center". Click " License Update ".

CodeMeter Control Center		-		\times
File Process View Help				
License Events				
Leader Software License (Firm 130-3825618762	Name: Leader Software License (Firm Code6000010) Serial: 130-3825618762 Version: CmActLicense: 3:00			
	Status: Status License activated			
CodeMeter service is running.			Web A	dmin

9. Click "Next >".

		?	×					
~	CmFAS Assistant							
	Welcome to the CmFAS Assistant!							
	The CodeMeter Field Activation Service (CmFAS) assistant helps you adding, chang deleting licenses from the license management system CodeMeter.	ing and						
	With the CmFAS assistant you can create license request files, which you can send to the vendor of the software by email. You can also import the received license update files with the CmFAS assistant into the license management and create a receipt of the import for the vendor.							
	Next >	Help	p					

10. Check "Create license request" and click "Next >".

? >	<
← ⓒ CmFAS Assistant	
Please select the desired action	
O Create license request	
Choose this option if you want to create a license request file in order to send it to the vendor of the software.	
🔿 Import license update	
Choose this option, if you received a license update file from the software vendor and want import this file.	to
🔿 Create receipt	
Choose this option if you want to confirm the successful import of a license update file for the software vendor.	
Next > Help	

11. Click "..." to set the output destination of the License Request File (.WibuCmRaC) to the USB memory stick. Then, click "Commit" to save.

		?	×
CmFAS Assistant			
Please select the file name			
C:¥Users¥localuser¥l130-780487055.WibuCmRaC			
Select a file name for storing the license request file. Then click or	'commit' to crea	ate the t	file
Select a file name for storing the license request file. Then click or You can then send this file to the vendor by email.	n 'commit' to crea	ate the f	file.
Select a file name for storing the license request file. Then click or You can then send this file to the vendor by email.	n 'commit' to crea	ate the f	file.
Select a file name for storing the license request file. Then click or You can then send this file to the vendor by email.	n 'commit' to crea	ate the f	file.
Select a file name for storing the license request file. Then click or You can then send this file to the vendor by email.	n 'commit' to crea	ate the t	file.
Select a file name for storing the license request file. Then click or You can then send this file to the vendor by email.	n 'commit' to crea	ate the t	file.

12. Click "Finish" and then remove the USB memory stick from the offline PC.



 Connect the USB memory stick to the online PC. Click "Select File" and choose the "License Request File (.WibuCmRaC)" from the USB memory stick. Click "Start Activation Now".

▼ 🤯 sh-61-522 (7+2/23) - 67- × NI 222)1/((11)-midniquebi0) ×	□ 19-7-電子株式会社 - カレンダー × 0 ChatGPT	X CodeMeter License Cente	ww.×+		- σ ×
← → C 🛱 ic.codemeter.com/94817/depot/autoUpdate.php				Baj ☆	D = = = :
😵 Rilliv97 🍷 0712 - 79511-87 🗴 Yahool JAPAN 🖌 Eshibitor My Page	🖬 AWS Skill Builder 🛛 Leader Company: Z 😵 7995/\$57773)	7 🏟 GLADIAS 💠 GLADIAS test 🚸	GLADIAS — WordP 🚯 GLADIAS QC Admin 🚯 GLAD	NAS-local 😇 SAP Business ByDes	» □ #^787577-7
L	eader		English 🖀 💌		
н	ame My Licenses				
Aut	omatic License Update				
2	Upload Request	Jownload Update	Upload Receipt		
w	alcome to automatic license update.				
н	re you find license updates for you CmContainer, pr	rovided by the vendor of the lice	ense.		
Те	check for license updates via file transfer:				
1.	Create a license request file for the CmContainer w identify our CmContainer.	here you want update. This lice	nse request file is needed to		
2. 3.	Select the created license request file. Click "Check License Updates".				
Ye	u can transfer these updates during the next step.				
Pick	license request file (*.WibuCmRaC)				
27	イルを選択目訳されていません				
	tart Activation Now		Direct license transfer		
© Le	ader Electronics Corporation				
Lega	Notice CodeMeter License Central WebDepot v21	.04a.276.501.ws4			

14. Click "Download License Update File Now". A "License Update File (.WibuCmRaU)" will be generated in the download folder. Save the "License Update File" to the USB memory stick and then remove the USB memory stick.

CosteMeter License Central Wit × +		- 0 X
	Leader English III (M. 1996)	
	Download License Update File Upload Request v Download Update Upload Receipt	
	To transfer your licenses via file - Second step "Download Update": 1. Click "Download License Update File Now" and save the file on your computer. 2. Ingort the loaners update file to the CnicOntainer with Secial 130-3825618762. This file can for example be imported with Accodentee Courd Cancer: Invel anvects 3. After you have successfully transferred the license update file to the OmContainer, click "Next" to confirm the license cancel.	
	Download License Update File Now Next Direct license transfer	
	If y Learnes Cleader Electronics Corporation	
	Logal Notice CodeMeter License Central WebDepot v21.04a.276.501.wo4	

15. Connect the USB memory stick to the offline PC. From the desktop, click "Start" then select "CodeMeter" to launch the "CodeMeter Control Center". Click "License Update ".

S CodeMeter Control Center		_		×
File Process View Help				
License Events				
Leader Software License (Firm 130-3825618762	Name: Leader Software Licence (Firm Code 6000010) Serial: 130-3825618762 Version: CmActLicence 3.00			
	Status: Statuse Status			
CodeMeter service is running.			WebAd	dmin

16. Click "Next >".



17. Check "Import license update" and click "Next >".

		?	×
←	CmFAS Assistant		
	Please select the desired action		
	🔘 Create license request		
	Choose this option if you want to create a license request file in order to send it vendor of the software.	to the	
	O Import license update		
	Choose this option, if you received a license update file from the software vendor import this file.	and w	ant to
	🔿 Create receipt		
	Choose this option if you want to confirm the successful import of a license upda the software vendor.	te file	for
	Next >	Hel	Þ

18. Click "..." to select the "License Update File (.WibuCmRaU)" from the USB memory stick, then click "Commit".



19. "Import Update successful." will be displayed. Click "OK".

←	CmFAS As:	sistant	?	×
	Please select	the file name		
	CodeMeter	· ? ×	WibuCmRaU	
	i	Information: Import Update successful.	∍ is stored on your computer. Then click on	
		ОК		
			Commit He	lp

20. Click "Finish".

	?	×
← ⓒ CmFAS Assistant		
The license update has been successfully imported.		
You will find details for the imported licenses in the CodeMeter WebAdmin. In receipt for the vendor please click <u>here</u> .	order to cre	ate a
Finish		lelp

21. Confirm that the "Status" shows "License activated." Click "License Update".

· · · · · ·			
S CodeMeter Control Center	-		\times
File Process View Help			
License Events			
- Lander Software Licence (Firm			
Local Section (International Control of			
Serial: 130-3025618762			
Version: GmActLicense 3.00			
Status: 🚳 License activated			
License Indete Remove License			
CodeMeter service is running		WebA	Idmin
		VIGDIN	

22. Click "Next >".

	?	\times
← ⓒ CmFAS Assistant		
Welcome to the CmFAS Assistant!		
The CodeMeter Field Activation Service (CmFAS) assistant helps you adding, cha deleting licenses from the license management system CodeMeter.	nging and	I
With the CmFAS assistant you can create license request files, which you can set of the software by email. You can also import the received license update files wi assistant into the license management and create a receipt of the import for the v	nd to the th the Cm vendor.	vendor IFAS
Next >	He	lp 🛛

23. Check "Create receipt" and click "Next >".

	?	×
← ⓒ CmFAS Assistant		
Please select the desired action		
Create license request		
Choose this option if you want to create a license request file in order to a vendor of the software.	send it to the	e
🔘 Import license update		
Choose this option, if you received a license update file from the software import this file.	vendor and	want to
Create receipt		
Choose this option if you want to confirm the successful import of a licens the software vendor.	se update fil	e for
Next >	Н	elp

24. Click "..." to set the output destination of the Receipt (.WibuCmRaC) to the USB memory stick. Then, click "Commit" to save.



25. Click "Finish" and then remove the USB memory stick from the offline PC.

	?	×
← ⓒ CmFAS Assistant		
The license receipt file has been successfully created.		
The license receipt file has been successfully created. You can send it now to the vendor of the software by email.		
Finish		lelp

26. Connect the USB memory stick to the online PC. Click "Next".

CadeMeter License Central Will X +		- 0 ×
← → O St /lc.codemeter.com/94817/depot/continue.php		1 x D 2 + 1
	Nome Py clenses	
	Download License Update File	
	Upload Request v Download Update Upload Receipt	
	To transfer your licenses via file - Second step "Download Update":	
	1. Click "Download License Update File Now" and area the file on your computer. 2. Innort the Lense update file to the "Concontainer with Serial 130-3225613762. This file can for example be imported with Codeleter Control Center, How it works 3. After you have successfully transferred the license update file to the CmContainer, dick "Next" to confirm the license transfer.	
	Download License Update File Now Next. Direct license transfer	
	My Licenses	
	© Leader Electronics Corporation	
	Legal Notice CodeMeter License Central WebDepot v21.04a.276.501.ws4	

27. Click "Select File" and choose the "License Receipt File(.WibuCmRaC)" from the USB memory stick. Click "Upload Receipt Now".

B Caldeter Sense Const Dir X + C Caldeter Sense Const Dir X + C C Caldeter Sense Const Mal17/depolycontrue ptp	۶ſ				 • • • • • •
+ + or (to iccolementer.com/9411//lepot/contrue.ptp Leadle Home M	51				
	er				
Home			English		
	y Licenses				
Confirm Lice	ense Transfer				
Up	load Request 🗸	Download Update	Upload Receip		
To transfer y	our licenses via file - Third step "I	Upload Receipt":			
1. Create a lic can for exa 2. Select - 3. Click "Uplo	ense receipt file from the CmContain mple be created with CodeMeter Cor rreated license receipt file. ad Receipt Now [*] .	ter with Serial 130-3825618762 htrol Center. How it works 🖬	and Firm Code 6000010.	This file	
If you haven't	imported the license update file yet,	, you can download it again. Click	"Back" to get to the downk	bad page.	
Pick license rec	eipt file (*.WibuCmRaC)				
ファイルを継択 Upload Rece	ipt Now Back		Direct lice	inse transfer	
My Licenses					
	and a Comparation				
© Leader Electro	onics corporation				

3. License Activation

28. "License transfer completed successfully." will be displayed. Click "OK". The activation of the new license is now complete.

CodeMeter License Central Wir X + + + + O I License Central Wir X +				陶女	- 0 ×
	Leader	English	(現) (四)		-
	Home My Licenses				
	License Transfer Successfully Completed				
	The license transfer has been completed successfully.				
	OK				
	© Leader Electronics Corporation				
	Legal Notice CodeMeter License Central WebDepot v21.04a.276.501.ws4				

3.3.4 License Cancellation

- 1. On the online PC, copy the Ticket ID provided in the email.
- 2. Click the URL of the "WebDepot" website for performing the activation process, as provided in the email.
- 3. "WebDepot" will be displayed in your internet browser.

A Constanting of the second seco	a v
 ← → O II kcolmetric control III (supplindes.php 	e i
English as B	
Home Auto Update	
Welcome to CodeMeter License Central WebDepot	
Welcome to CodeMeter License Central WebDepot. You can transfer your licenses to your CmContainer using this WebDepot. Please enter your ticket and cick "Next".	
Ticket:	
Not	
© Leader Electronics Corporation	
Legal Notice CodeMeter License Central WebDepot v21.04a.276.501.ws4	

4. Enter the Ticket ID and click "Next".

CodeMeter License Central Wei × +						o ×
← → C 🛱 Ic.codemeter.com/94817/depot/index.php				B∥ ☆	5	€ ∃
	Leader	English	N N			
	Home Auto Update					
	Welcome to CodeMeter License Central WebDepot					
	Welcome to CodeMeter License Central WebDepot. You can transfer your licenses to your O WebDepot. Please enter your ticket and click "Next".	mContainer using this				
	Ticket: T86JW-LYKJF-MT56J-HABKW-PWKC5					
	Next					
	© Leader Electronics Corporation					
	Legal Notice CodeMeter License Central WebDepot v21.04a.276.501.ws4					

5. "My Licenses" will be displayed. Click "Auto Update".

CodeMeter License Central We × +						- 0 X
← → Ø IS locodemeter.com/94817/depot/overview.php					離 ☆	요 문 🌻 :
	Leader			English a		
	Home My Licenses					
	My Licenses					
	Name	Activated On	CmContainer	Status		
	SFR-Fit Software License BFR-Fit Software License	-	o 130-1789614573	Auto Update		
	Auto Update					
	© Leader Electronics Corporation					
	Legal Notice CodeMeter License C	entral WebDepot v21.04a.276.50	Lws4			

6. "Available Automatic License Updates" will be displayed. Click "File-based license transfer" at the bottom right.

*Since the online PC does not have the "CmContainer" required for license activation, an error message will be displayed.

CodeMeter License Central With X +							- 0 ×
← → ♂ (≌ lc.codemeter.com/94517/depot/assignedLicens	s.php					1 ☆ ☆	🛓 🤤 i
	Leader			English 🚳 🖥	E		
	Home My Licenses						
	Available Automatic License	Updates					
	To transfer your automatic license 1. Make sure that the CmContainer - not connected to this computer, o 2. Click "Transfer License Updates N	e updates to CmContainer: with Serial 130-1789614573 onnect it now and click "Resca ow".	is connected to this comput n for CmContainers".	er. If this CmContainer is			
	Name	Activated On	CmContainer	Status			
	SFR-Fit Software License SFR-Fit-Software ticense	- 2024-06-21-07020139	130-1789614573	Auto Update			
	Error The CmContainer with serial liconse transfer. 0x1808810E CodeMeter License Central W 2024-06-11 07:40:19 (UTC)	130-1789614573 was not fou WebDepot v21.04a.276.501.ws	nd. Please connect it to your	PC or use file-based			
	Rescan for CmContainers			File-based license trans	fer		
	© Leader Electronics Corporation						
	Legal Notice CodeMeter License Cent	ral WebDepot v21.04a.276.50	Lws4				

7. "License Auto Update" will be displayed.

 ★ m+4e+v122 (予約)(74) - 45- × ■ № 変換(14)(11)- a 	nchikowskill 🗴 🔯 9-5-978568 - 51/75- 🗴 🖉 CherGPT	× 🖪 CodeMeterLices	re Central Wer 🗙 🕂		- 0 X
← → ♂ (# lc.codemeter.com/94817/depot/autoUp	sdate.php				\$8 ☆ D = ₹ ⊕ :
🕲 865977 👎 0579-7957687 🐭 Yahaad JADAN 🖌 Ka	hibitor My Page 🔤 AWS Skill Builder 🛛 🔁 Leader Company Z 😌 731	9F\$657479 9 🏘 GLADIAS 🛛 🏘 GLADIAS Ini	🚯 GLADIAS — WordP 🚯 GLAD	IAS QC Admin 🛛 🚯 GLADIAS-local 🗁 SAP	Basireess ByDes 20 19/10/2017/7-
	Leader		English		
	Home My Licenses				
	Automatic License Update				
	Upload Request	Download Update	Upload Recei	ipt	
	Welcome to automatic license update.				
	Here you find license updates for you CmCor	ntainer, provided by the vendor of th	ie license.		
	To check for license updates via file trans	fer:			
	 Create a license request file for the CmCos identify our CmContainer. Select the created license request file. Click "Check License Updates". 	ntainer where you want update. Thi	s license request file is neede	ed to	
	You can transfer these updates during the n	ext step.			
	Pick license request file (*.WibuCmRaC)				
	ファイルを選択 選択されていません				
	Start Activation Now		Direct li	icense transfer	
	© Leader Electronics Corporation				
	Legal Notice CodeMeter License Central WebD	Depot v21.04a.276.501.ws4			

8. Connect the USB memory stick to the offline PC. From the desktop, click "Start then select "CodeMeter" to launch the "CodeMeter Control Center". Click "License Update".

S CodeMeter Control Center		-		×
File Process View Help				
License Events				
Leader Software License (Firm) 130-3825618762	Name: Leader Software License (Firm Code\$800010) Serial: 100-3825610762 Version: C:mActLicense: 3.00			
	Status: 🞯 License activated			
	Licence Update Remove License			
CodeMeter service is running.			Web A	dmin

9. Click "Next >".

	?	×
 CmFAS Assistant 		
Welcome to the CmFAS Assistant!		
The CodeMeter Field Activation Service (CmFAS) assistant helps you adding, char deleting licenses from the license management system CodeMeter.	nging and	ł
With the CmFAS assistant you can create license request files, which you can sen of the software by email. You can also import the received license update files with assistant into the license management and create a receipt of the import for the v	id to the h the Cm endor.	vendor IFAS
Next >	Не	lp

10. Check "Create license request" and click "Next >".

7	P	\times
← ⓒ CmFAS Assistant		
Please select the desired action		
Create license request		
Choose this option if you want to create a license request file in order to send it to vendor of the software.) the	
○ Import license update		
Choose this option, if you received a license update file from the software vendor a import this file.	ind war	nt to
🔘 Create receipt		
Choose this option if you want to confirm the successful import of a license update the software vendor.	; file fo	ır
Next >	Help	

11. Click "..." to set the output destination of the License Request File (.WibuCmRaC) to the USB memory stick. Then, click "Commit" to save.

	?	×
CmFAS Assistant		
Please select the file name		
U:#Users#localuser#[130=780487055.WibuUmRaC	nit' to create the	file.
Select a file name for storing the license request file. Then click on 'comr		
C#Users#localuser# 130-780487055.WibuCmRaC Select a file name for storing the license request file. Then click on 'comm You can then send this file to the vendor by email.		
C#Users#localuser# 130-780487055.WibuCmRaC Select a file name for storing the license request file. Then click on 'comr You can then send this file to the vendor by email.		
C#Users#localuser# 130-780487055.WibuCmRaC Select a file name for storing the license request file. Then click on 'comr You can then send this file to the vendor by email.		
C#Users#localuser# 130-780487055.WibuCmRaC Select a file name for storing the license request file. Then click on 'comr You can then send this file to the vendor by email.		
C:#Users#localuser# 130-780487055.WibuCmRaC Select a file name for storing the license request file. Then click on 'comm You can then send this file to the vendor by email.		
C:#Users#localuser# 130-780487055.WibuUmRaC Select a file name for storing the license request file. Then click on 'comr You can then send this file to the vendor by email.		

12. Click "Finish" and then remove the USB memory stick from the offline PC.



 Connect the USB memory stick to the online PC. Click "Select File" and choose the "License Request File(.WibuCmRaC)" from the USB memory stick. Click "Start Activation Now".

👻 委 かきか22 (H078)O - X - N 変形 (H01-mbased) X - 🖾 (H-5-8298788) - 20 - F - ス ● Out071 X - ●
🔄 🕆 C 🛱 (codemeter.com/9807/dept/saturbjedate.php 🖏 🏠 🗋 🖓 🥏
B BL/97 C9(2): 75(1:72- W Taked UAAN ✓ Inhibiter My Pape). Barts Still Taketer Openper(Z. ② 79)755(772): CADAS ♥ GADAS == GADAS == GADAS =
Home My Licenses
Automatic License Update
Upload Request Download Upload Receipt
Welcome to automatic license update.
Here you find license updates for you CmContainer, provided by the vendor of the license.
To check for license updates via file transfer:
 Create a license request file for the CmContainer where you want update. This license request file is needed to identify our CmContainer.
2. Select the created lowne request file, 3. Cick "Check License Updates", "
You can transfer these updates during the next step.
Dick license request file (*.WibuCmRaC)
ファイルを選択、 穴されていません
Start Activation Now Direct license transfer
© Leader Electronics Corporation
Legal Notice CodeMeter Licenses Contral WebDepot v21.046.276.501.ws4

14. Click "Download License Update File Now". A "License Update File (.WibuCmRaU)" will be generated in the download folder. Save the "License Update File" to the USB memory stick and then remove the USB memory stick.

CooleMeter License Central Wit × +			- 0 ×
€ → C (\$ /lc.codemeter.com/94817/depot/continue.php			월 ☆ ① 초 🗣 i
	Leader	English 🗱 🗷	
	Home My Licenses		
	Download License Update File		
	Upload Request V Download Update	Upload Receipt	
	To transfer your licenses via file - Second step "Download Update":		
	 Clock "Download Licence Luddle File Nov" and save the file on your computer. Insport this knews explate file the Cincrotancer with Seriel 130-3025510762. This fil imported with CodeMeter Cantrol Center, How it auxist 2 After you have successfully transferred the licence update file to the CinContainer, dick "It transfer. 	e can for example be lext* to confirm the license	
	Download License Update File Now Next	Direct license transfer	
	My Licenses		
	© Leader Electronics Corporation		
	Legal Notice CodeMeter License Central WebDepot v21.04a.276.501.ws4		

15. Connect the USB memory stick to the offline PC. From the desktop, click "Start" then select "CodeMeter" to launch the "CodeMeter Control Center". Click "License Update".

S CodeMeter Control Center -		×
File Process View Help		
License Events		
Leader Software License (Firm Name: Leader Software License (Firm Code 6000010) Serial 130-3825618762 Version: CmActLicense 3:00		
Status: S License activated		
CodeMeter service is running.	Web/	Admin

16. Click "Next >".

	?	×
 CmFAS Assistant 		
Welcome to the CmFAS Assistant!		
The CodeMeter Field Activation Service (CmFAS) assistant helps you adding, cha deleting licenses from the license management system CodeMeter.	nging and	ł
With the CmFAS assistant you can create license request files, which you can ser of the software by email. You can also import the received license update files wit assistant into the license management and create a receipt of the import for the v	nd to the th the Cm vendor.	vendor 1FAS
Next >	He	lp

17. Check "Import license update" and click "Next >".

	?	×
← ⓒ CmFAS Assistant		
Please select the desired action		
○ Create license request		
Choose this option if you want to create a license request file in order to se vendor of the software.	nd it to the	!
Import license update		
Choose this option, if you received a license update file from the software ve import this file.	endor and v	want to
🔘 Create receipt		
Choose this option if you want to confirm the successful import of a license the software vendor.	update file	e for
Next >	He)p

18. Click "..." to select the "License Update File (.WibuCmRaU)" from the USB memory stick, then click "Commit".



19. "Import Update successful." will be displayed. Click "OK".

←	CmFAS As	sistant		?	×
	Please select	the file name			
	🞯 CodeMeter	· ? >	<	WibuCmRaU	
	i	Information: Import Update successf	ul.	∍ is stored on your computer. Then click on	
		ОК			
				Commit Hel	p

20. Click "Finish".

	?	\times
 CmFAS Assistant 		
The license update has been successfully imported.		
You will find details for the imported licenses in the CodeMeter WebAdmin. In or receipt for the vendor please click <u>here</u> .	der to creat	te a
Finish	Не	lp

21. Confirm that the "Status" shows "License activated." Click "License Update".

ScodeMeter Control Center		-		×
File Process View Help				
License Events				
Leader Software License (Firm 130-3823618762	Name: Leader Software License (Firm Code 5000010) Serial: 130-3825618762 Version: CmActLicense: 300 Status: Status: License activated			
CodeMeter service is running.			WebA	dmin

22. Click "Next >".

	?	×
← ⓒ CmFAS Assistant		
Welcome to the CmFAS Assistant!		
The CodeMeter Field Activation Service (CmFAS) assistant helps you adding, chan deleting licenses from the license management system CodeMeter.	iging and	
With the CmFAS assistant you can create license request files, which you can sen of the software by email. You can also import the received license update files with assistant into the license management and create a receipt of the import for the ve	d to the v n the Cmil endor.	/endor FAS
Next >	Hel	p

23. Check "Create receipt" and click "Next >".

	?	×
← ⓒ CmFAS Assistant		
Please select the desired action		
Create license request		
Choose this option if you want to create a license request file in order to seno vendor of the software.	d it to the	
🔘 Import license update		
Choose this option, if you received a license update file from the software ver import this file.	ndor and v	vant to
Create receipt		
Choose this option if you want to confirm the successful import of a license u the software vendor.	ıpdate file	e for
Next >	He	lp

24. Click "..." to set the output destination of the Receipt (.WibuCmRaC) to the USB memory stick. Then, click "Commit" to save.



25. Click "Finish" and then remove the USB memory stick from the offline PC.

	?	\times
← ⓒ CmFAS Assistant		
The license receipt file has been successfully created.		
The license receipt file has been successfully created. You can send it now to the vendor of the software by email.		
Finish	Не	In
Finish	Не	lp

26. Connect the USB memory stick to the online PC. Click "Next".

CadeMeter License Central Wei X +		- 0 ×
€ → Ø St (scodemeter.com/94817/depot/continue.php		🕸 🕸 🖸 🕹 🖨 i
	Leader English un (M	
	Home My Licenses	
	Download License Update File	
	Upload Request v Download Update Upload Receipt	
	To transfer your licenses via file - Second step "Download Update"; 1. Cick: "Download License Update file Now" and save the file any computer. 2. Import this increase update file the Uncorrecting visit Secial 130-3025610762. This file can for example be imported with CodeNeter Control Center. How it works [] 3. After you have successfully transferred the learnese update file to the CmContainer, click: "Next" to confirm the learne transfer. Download License Update file Now Next Detect License transfer	
	Ky Loaves Converses Converses Converses	
	Legal Netroe CodeMeter License Cantral WebDepot v21.04s.276.501.we4	

27. Click "Select File" and choose the "License Receipt File(.WibuCmRaC)" from the USB memory stick. Click "Upload Receipt Now".

CodeMeter Genne Central Wei X +		- 0 X
← → ♂ 年 Ic.codemeter.com/94817/depot/continue.php		월 ☆ ① 초 🗣 E
	Confirm License Transfer	
	Upload Request v Download Update Upload Receipt	
	To transfer your licenses via file - Third step "Upload Receipt": 1. Create a leaves receipt file from the CmContainer with Serial 130-8235618752 and Firm Code 6000010. This file can for example be created with CodeHear Control Center: How & works S 2. Select the created leaves means file. 3. Click "Upload Receipt how". If you haven't imported the license update file yet, you can download it again. Click "Back" to get to the download page.	
	Pick license receipt file (*.WibuCmRaC) 27-7/J-24HI 30-3825618762.WibuCmRaC	
	Upload Receipt Now Back Direct license transfer	
	My Licenses	
	© Leader Electronics Corporation	
	Legal Notice CodeMeter License Central WebDepot v21.04a.276.501.ws4	

28. "License transfer completed successfully." will be displayed. Click "OK". The activation of the new license is now complete.

CodeMeter Ucerse Central Wei X +			No D	- 0	×
	Leader	English		1	
	Home My Licenses				
	The license transfer has been completed successfully.				
	© Leader Electronics Corporation				
	agal Notice CodeMeter License Central WebDopot v21.04a.376.501.ws4				

- 3.3.5 License Transfer to Another PC
 - Perform various installations on the destination PC.
 [See "2. Installation"]
 - Cancel the license on the original PC.
 [See "3.2.4 License Cancellation"]
 - Activate the license on the destination PC.
 [See "3.2.1 New License"

4. License Confirmation

4.1 Checking Activation Status

1. To check the license, right-click the "CodeMeter icon" in the "Windows Taskbar" and click "WebAdmin".



Or, from "Start", click "CodeMeter" -> "CodeMeter Control Center" -> "WebAdmin". "WebAdmin" will be displayed in your browser.

😋 CodeMeter Control Center	– 🗆 X
<u>File Process View H</u> elp	
License Events	
SFR-Fit Trial CmActLicense 130-3108164547	Name: SFR-Fit Trial CmActLicense Serial: 130-3108164547 Version: CmActLicense 3.00
	Status: 🎯 License activated
Lice	nse Update Remove License
CodeMeter service is running.	WebAdmin

2. Description of the "WebAdmin" screen

S WebAdmin C	ontainer x +					-	- 0	×
C G	(i) localhost:22352/container/cmcontainer_details.html?BoxSeria	I=130-3108164547	A	аљ	ល់ រ	î≞ ⊥		
	L Code	Meter WebAdmin					C∽	
Dashboa	rd Container - License Monitoring - Diagnosis	 Configuration < Info 		0		a allah (I	*	
	SFR-Fit Trial CmActLicense (130-3108164547) SFR-Fit Trial CmActLicense SFR-Fit Trial CmActLicense Licenses CmContainer Info G001567 Leader Electronics Corporation	<u>130-3108164547</u> 2	CmActL	() icense	999 E	o0	JS) V	
Produc	t Code Name 3170 - 3	Unit Counter Valid Until n/a n/a 4	Lie	cense Qu	iantity F	eature M n/a	ap	
Current No.	Server: localhost (127.0.0.1) 🤗 🌘	WebAdmin Version: 7.	40					

NO.	Explanation.
1	Name of CmContainer
2	CmContainer serial number
3	License Name
4	License expiration date

5. Message at Software Startup

5.1 Start Error

This message is displayed when "CodeMeter Runtime" is not installed. Refer to "2 Install" to install "CodeMeter Runtime".

SFR_Fit_v11.exe: Start Error	
Leader SFR-Fit	SFR_Fit_v11.exe: Start Error One of the following licenses is required: *CodeMeter 6001567:3170 Failure reason: CmDongle runtime system is not installed!
www.leader.co.jp	OK

5.2 No license found!

License activation has not been completed. Refer to "3 License Activation" to activate the license.

CodeMeter - No license found!	×
Leader SFR-Fit	No license found! There was no CmContainer with an appropriate license CodeMeter 6001567:3170 for this software found on your computer. To use this software you need a CmContainer with the license for this software. Please plug the appropriate CmDongle into your computer or activate your CmActLicense.
	<u>R</u> etry <u>C</u> ancel
	Please contact us for more information on obtaining a license.
www.leader.co.jp	[Contact]

Button	Explanation.
Retry	Not used.
Cancel	Exit the application.
Contact	Open the Reader Electronics support page as shown in Section "5.5 Support Page."

5.3 Licensing almost expired!

This message is displayed when the license expiration date is less than 60 days. Please contact our sales representative for renewal procedures

CodeMeter - License almost expire	d!	×
Leader SFR-Fit	License almost expired! This software is protected for temporary use. The expiration time has almost expired.	-
	Dk Cancel Please contact us for more information on obtaining a license. Information on obtaining a license.	
www.leader.co.jp	Contact	

Button	Explanation
Ok	Launch the application.
Cancel	Exit the application.
Contact	Open the Reader Electronics support page as shown in Section "5.5 Support Page."

5.4 Your license has expired!

This message is displayed when the license expires. Please contact our sales representative for renewal procedures.

CodeMeter - 有効期限が切れました!		×
Leader SFR-Fit	相対有効期限が切れました! 使用期間が過ぎたためアフリケーションを超動することがで きません。	
	再試行 キャンセル ライセンス取得に関する詳細につきましてはお問い合わせく だとい。	
www.leader.co.jp	お問合せ	

Button	Explanation
Retry	Not used.
Cancel	Exits the application
Contact	Open the Reader Electronics support page as shown in Section "5.5 Support Page."

5.5 Support Page

						-		×
	imicaetati				0.0	~		
	and country.		Contact myLanderLogia	0 6	- 10	1-	w	
			Contract insystement tages	Q 18	Bana			-
Leader								
Home / Productinfo / Support / CompanyInfo / News / Careers								
Home > Contact								
								- 1
Contact								- 1
te entities there are	telenhene (emeil							
inquiries through telephone & email								
We also accept inquiries about our products and company by telephone and e-mail. Promotion apply extension of the large investment of the apply and product and the large transfer and the large investment of the large inves								
peperang on the content of	one inquiry, we may take some time to reply o	i may not reply in some	cases. There you for your unsersationing.					
	USA							
		Disease (UIC)	501-102-(400					
	General reception Repair & calibration New York Service Center	Phone (03)						
		E-mail	info@leaderamerica.com					
		Phone (US)	201-355-4850					
		E-mail	service@leaderamerica.com					
	EUROPE							

Leader Electronics Corporation

2-6-33 Tsunashima-higashi, Kohoku-ku, Yokohama-shi, Kanagawa, 223-8505, Japan www.leader.co.jp/en